













VOLKSWAGEN single phone key

Answering an incoming call	Press	
Hanging up a call:	Press long	
Rejecting a call:	Press long	
Voice dialling:	Press	
Last number redialling:	Press long	
Discreet mode:	Press	
Back to car kit:	Press	
Turning the volume up:	Press	VOLUME ↑
Turning the volume down:	Press	VOLUME ↓
Entering menu functions:	Press twice	
Scrolling menu function:	Press	VOLUME ↑
		VOLUME ↓
Confirming a function:	Press	
Cancelling a function:	Press long	
Entering MUSIC mode:	Press 3 times	
Scrolling songs: Search alphabetically:	Press	SEEK ►
		◄ SEEK
Leaving MUSIC mode:	Press 3 times	
Car kit resetting:	Press	VOLUME ↓ followed by
		VOLUME ↑ 5 times























VOLKSWAGEN

GOLF 2004>
 PASSAT 2004>
 PASSAT CC 2007>
 TOURAN 2004>
 TOUAREG 2004>
 EOS 2006>
 TIGUAN 2008>



VOLKSWAGEN double phone key

Answering an incoming call	Press	
Hanging up a call:	Press	
Rejecting a call:	Press	
Voice dialling:	Press	
Last number redialling:	Press long	
Discreet mode:	Press	
Back to car kit:	Press	
Turning the volume up:	Press	VOLUME 
Turning the volume down:	Press	VOLUME 
Entering menu functions:	Press twice	
Scrolling menu function:	Press	VOLUME 
		VOLUME 
Confirming a function:	Press	
Cancelling a function:	Press	
Entering MUSIC mode:	Press long	
Scrolling songs: Search alphabetically	Press	SEEK 
		 SEEK
Leaving MUSIC mode:	Press long	
Car kit resetting:	Press	VOLUME  followed by
		VOLUME  5 times



VOLKSWAGEN

GOLF 2004>
 PASSAT 2004>
 PASSAT CC 2007>
 TOURAN 2004>
 TOUAREG 2004>
 EOS 2006>
 TIGUAN 2008>



VOLKSWAGEN WITHOUT PHONE KEY

Answering an incoming call:	Press	VOLUME ↑
Hanging up/Rejecting a call:	Press	VOLUME ↓
Voice dialling:	Press followed by	VOLUME ↑ VOLUME ↓
Last number redialling:	Press Quickly and then	VOLUME ↑
	press for long	VOLUME ↓
Discreet mode/Back to car kit mode:	Press	VOLUME ↑
Adjusting the volume:	Press ^{Up} VOLUME ↑ followed by	VOLUME ↓
	Press _{Down} VOLUME ↓ followed by	VOLUME ↑
Entering menu functions:	Press	SEEK ►
	followed by	SEEK ◀ TWICE
Scrolling menu fuctions:	Press ^{Forward} VOLUME ↑ followed by	VOLUME ↓
	Press _{Backward} VOLUME ↓ followed by	VOLUME ↑
Confirming/cancelling a function:	Press ^{Confirming}	VOLUME ↑
	Press _{Cancelling}	VOLUME ↓
Entering/Leaving MUSIC mode:	Press ^{Forward}	SEEK ►
	Press _{Backward}	SEEK ◀
Scrolling songs:	Press ^{Forward}	SEEK ►
	Press _{Backward}	SEEK ◀
Car kit resetting: <small>Only MKI9000</small>	VOLUME ↓ Press followed by	VOLUME ↑ 5 times



VOLKSWAGEN

- GOLF 2004>
- PASSAT 2004>
- PASSAT CC 2007>
- TOURAN 2004>
- TOUAREG 2004>
- EOS 2006>
- TIGUAN 2008>

